

BASIC OPERATION OF AMX CONTROL



The AMX Display is the new wave of control panel for USD's new console design. The **AMX Console DOES NOT REQUIRE A KEY**. The following classrooms have been outfitted with this new console so any instructor requesting a key does not need one.

OPERATION: If no one has used the console recently, the screen maybe 'DARK' (asleep), touching anywhere on the screen will 'wake it up'.

The display controls 'everything'; lowers an electric screen, turns on the data projector, adjusts the volume. The User chooses what source to send to the data projector (in room computer, laptop (still needs to be hooked to cables supplied, stills a MAC adapter supplied by the user), document camera (in side drawer) and Blu-Ray DVD player (this unit will also play regular DVD's and foreign PAL DVD's).

SPECIAL NOTE: **THERE IS NO VHS PLAYER** (in the AMX Console ONLY!) – IMS WILL NO LONGER SUPPORT THIS FORMAT. PLEASE REFER ALL CALLERS TO EITHER ARTHUR RUSH x5954 or SHAHRA MESKATY x2298, Sr. Director, Academic Technology Services.

Accessing (or selecting the desire source) will even allow the user to 'play', 'fast-forward', 'pause' or 'access DVD menu' (so to skip to a DVD chapter).