

## BASIC OPERATION OF AMX CONTROL



The AMX Display is the new wave of control panel for USD's new console design. The **AMX Consoles (the slim line Podium II and the wider Podium III) DO NOT REQUIRE A KEY.** The following classrooms have been outfitted with this new console so any instructor requesting a key does not need one. Each semester, additional classrooms will be outfitted with the AMX control Podium III.

**SLP 412 (Student Life Pavilion)**

**MAHER 207, 222, 224**

**SERRA 102, 204, 212, 214b, 312, 314**

**OLIN 129, 130, 125 – 126 – 225 – 226 – 325 – 326 – 329 – 330**

**CAMINO 153, 101a, 101b, 109, 111, 115, 117, 119**

**LRC 208, 210, 212**

OPERATION: If no one has used the console recently, the screen maybe 'DARK' (asleep), waving your hand in from of its sensor or touching anywhere on the screen will 'wake it up'.

The display controls 'everything'; lowers an electric screen (if the room has been outfitted with one), turns on the data projector, allows adjustment of the volume. The User chooses what source to send to the data projector (**in room computer, guest laptop** (still needs to be hooked to cables supplied, still needs a MAC adapter supplied by the user), **document camera** (in side drawer in included) and **VHS/ DVD combo player**. (The controls for the combo player appear on the display screen and allow all normal functions so there is no need for a handheld remote control).

All equipment is easily assessable and secured inside the podium.